


91-700 Test program for airbag and belt tensioner (up to 09/87) and airbag 1/3

Special tools




Note

The tester 126 589 10 21 00 must always be used when testing the airbag and belt tensioner restraint system. (For test instructions, see paragraphs entitled "Test instructions for tester 126 589 10 21 00").

If other testers are used, there is a danger of triggering the airbag and belt tensioner restraint system.

- 1 Indicator lamp for internal power supply
- 2 Indicator lamp for reserve power source
- 3 Digital display
- 4 Test jacks for external voltage and resistance measurements
- 5 Test selector switch
- 6 Ground button (to test the insulation resistance)
- 7 Connection for external power supply
- 8 Cable for external power supply
- 9 Test cable for external voltage and resistance measurements



182-20672

Connecting tester

1 Turn ignition key to position "0", disconnect negative terminal of battery and cover.


2 Access test coupling/plug connection for airbag, 10-pin (X29/9):

In model 124, on passenger's side foot rest or on the plate below this.




Before disconnecting the 10-pin plug connection (X29/9) to connect or disconnect the tester, always turn the ignition key to position "0" and disconnect and cover the negative terminal of the battery. It is essential to ensure that the disconnected battery terminal cannot automatically come into contact with the negative pole.

X29/9 10-pin plug connection



3 Disconnect 10-pin plug connection (X29/9) and connect tester with the 10-pin plug of the cable harness.


4 Reconnect battery for test.



Connecting tester for use for external voltage or resistance measurements.

1 Connect cables (8) for tester power supply to connection (7) and couple to positive and negative poles of battery.

2 Plug test cables (9) into test jacks (4).




3 When measuring voltages, turn test selector switch to position "8". The display is in volts (V).


4 When measuring resistances, turn test selector switch to position (9). The display is in ohms (Ω).

Note

If the tester is used for external voltage or resistance measurements, it must be disconnected from the 10-pin plug of the airbag and belt tensioner cable harness.



182-20671




Wiring diagram for airbag and driver's and passenger's belt tensioner system with 4 carbon contacts and voltage transformer (from production launch)

A1e15	Instrument cluster, RS warning lamp, airbag	X28/4	Plug connection, airbag, detonator
C1	Reserve power source, airbag	X28/5	Collector ring, detonator, airbag
N2/2	Control unit, airbag with belt tensioner	X29/9	Test coupling/plug connection, airbag, 10-pin
N24	Voltage transformer, airbag		
R12/1	Detonator, belt tensioner, front left	a	Fuse box, terminal 15 R, fuse 18, input, via X28/2
R12/2	Detonator, belt tensioner, front right		Terminal 15 R to N2/2, N24, A1e15
R12/3	Detonator, airbag		
W12*	Main ground point, center console		
X28/2	Plug connection, power supply, airbag with belt tensioners		

* Marked "W" in wiring diagram

The plug pins 3, 5, 6, 7 and 8 in the bottom section of the plug are short-circuited when the 10-pin plug connection (X29/9) is disconnected. When disconnecting the connectors for the belt tensioner detonators (R12/1, R12/2) and the airbag detonator (R12/3), these are short-circuited.



Wiring diagram for airbag and driver's and passenger's belt tensioner system with control unit for airbag 1/3 (recognisable by inscription "Airbag 1/3" on the test coupling/plug connection, airbag X29/9)

- | | | | |
|-------|--|-------|---|
| A1e15 | Instrument cluster, warning lamp, airbag (RS, SRS) | X28/4 | Plug connection, airbag/detonator |
| N2/2 | Control unit, airbag with belt tensioner | X28/5 | Collector ring, detonator, airbag |
| R12/1 | Detonator, belt tensioner, left seat | X29/9 | Test coupling/plug connection, airbag, 10-pin |
| R12/2 | Detonator, belt tensioner, right seat | a | Model 124, fuse box, terminal 15 R, fuse 2. Input via X28/2 |
| R12/3 | Detonator, airbag | | |
| W12* | Main ground point, center console | | |
| X28/2 | Plug connection, power supply, airbag with belt tensioners | | |




* Marked "W" in wiring diagram



Note



In vehicles with airbag 1/3, the reserve power source for airbag (C1) and the voltage transformer for airbag (N24) are removed and the cable ends insulated. The plug pins 3, 5, 6, 7 and 8 on the bottom section of the plug are short-circuited when the 10-pin plug connection (X29/9) is disconnected. When disconnecting the connectors for the belt tensioner detonators (R12/1, R12/2) and the airbag detonator (R12/3), these are short-circuited.

Test program



a) The warning lamp (A1e15) for the restraint system in the instrument cluster fails to light up when the ignition key is turned to position 1 or 2 (ignition).







191-26830



b) After turning the ignition key to position "1", the warning lamp lights up but fails to go out again within 10 s or approx. 4 s in vehicles with airbag 1/3, or flickers intermittently during driving.

Checking airbag and belt tensioner system

Test step 1 (test selector switch position 1)
Test power supply for control unit (battery OK)
Connect tester to 10-pin plug of cable harness (see "Connecting tester").
Turn ignition key to position "1".

Reference value: battery voltage

Reference value
correct

Reference value
incorrect

Disconnect battery.
Disconnect tester from 10-pin plug of cable harness.
Connect tester for external resistance measurement.
Turn test selector switch to position "9".



182 - 20642

Using test rods, check black/red cable as far as 10-pin plug, connection no. 1, for open circuit.

Reference value: 0 – 1 Ω

Reference value correct

Reference value incorrect

Renew cable harness.
Check airbag and belt tensioner system.

End of test

Using test rods, check brown cable from 10-pin plug (X29/9), connection no. 4, to vehicle ground.

Reference value: 0 – 1 Ω


Reference value correct

Reference value incorrect


Intermittent open circuit in brown cable from 10-pin plug (X29/9), connection no. 4, to main ground point (W12) in center console.

Eliminate open circuit.
Check function of warning lamp (A1e15).

End of test



182 - 20645



Turn ignition key to position "0".
 Disconnect tester from 10-pin plug of cable harness.
 Connect tester for external measurement of voltage.
 Turn test selector switch to position "8".
 Disconnect 12-pin coupling from voltage transformer (N24).
 Turn ignition key to position "1".
 Check power supply to voltage transformer (positive test rod to 12, negative test rod to socket 1).
 Reference value: battery voltage

Reference value correct	Reference value incorrect
-------------------------	---------------------------

Turn ignition key to position "0".
 Turn test selector switch to position "9".
 Using both test rods, check cable from socket 6 to 10-pin plug 9 for open circuit.
 Reference value: 0 – 1 Ω

Reference value correct	Reference value incorrect
-------------------------	---------------------------

Renew voltage transformer (N24).
 Check function of warning lamp (A1e15).

Renew cable harness and check airbag and belt tensioner system.

End of test

End of test

Turn ignition key to position "0".
 Turn test selector switch to position "9".
 Using both test rods, check black/red cable from socket 12 to fuse box, terminal 15R, for open circuit.
 Reference value: 0 – 1 Ω

Reference value correct	Reference value incorrect
-------------------------	---------------------------

Open circuit in brown cable from socket 1 to main ground point.
 Check function of warning lamp (A1e15).

Renew cable harness and check airbag and belt tensioner system.

End of test

End of test

Test step 3

Test resistance of airbag detonator (R12/3).

To do this, turn steering wheel to full lock left and right several times.

Tester connected to 10-pin plug, ignition key in position "1".

Reference value: 2 – 6 Ω

Reference value correct

Reference value incorrect

To test insulation resistance (cable harness for short circuit to ground), press ground button (arrow).

Reference value: ≥ 20 k Ω (EEE)

Reference value correct

Reference value incorrect

Renew cable harness and check airbag and belt tensioner system.


End of test

Disconnect 2-pin plug connection (X28/4) under dashboard (to do this, disconnect and reconnect the battery).


Resistance ≥ 20 k Ω EEE (∞)

If resistance is lower, renew cable harness and check airbag and belt tensioner system. If resistance ≥ 20 k Ω EEE (∞), bridge 2-pin plug then read off resistance.

Reference value: 0 – 1 Ω



182-20643/1



107-20467

Reference value correct	Reference value incorrect
-------------------------	---------------------------

Renew cable harness and check airbag and belt tensioner system.

End of test

Remove airbag unit (to do this, disconnect battery).
 Bridge connection for airbag unit.
 Re-contact 2-pin coupling with 2-pin plug under dashboard (X28/4).
 Measure resistance.
 Reference value: 0 - 6 Ω


Reference value correct	Reference value incorrect
-------------------------	---------------------------

Renew airbag unit.
 Check function of warning lamp (A1e15).


End of test

Remove steering wheel.
 Bridge carbon contacts one after the other.
 Measure resistance.
 Reference value: 0 - 1 Ω


Reference value correct	Reference value incorrect
-------------------------	---------------------------





182-20641



182-20673



146-21167/1



Test step 4
Test resistance of belt tensioner unit

Tester connected to 10-pin plug, ignition key in position "1".


Reference value: 2 – 6 Ω (with 1 belt tensioner)
Reference value: 1 – 1.7 Ω (with 2 belt tensioners)



Reference value correct	Reference value incorrect
-------------------------	---------------------------

Check insulation resistance; to do this, press ground button.

Reference value: $\geq 20 \text{ k}\Omega$ (EEE) ∞

Reference value correct	Reference value incorrect
-------------------------	---------------------------





182-20697

Test step 5 is not required.

Test step 6
 Test charge of reserve power source (C1).
Not required for airbag 1/3

The reserve power source (C1, capacitor) is charged via the tester until the maximum voltage is reached.


Reference value: ≥ 9

Reference value correct	Reference value incorrect
-------------------------	---------------------------

Disconnect connection from reserve power source (C1).
 Bridge connection.
 Connect tester for external resistance measurement.
 Using test rods, measure resistance between connections 4 and 9 on 10-pin plug.

Reference value: $0 - 1 \Omega$

Reference value correct	Reference value incorrect
-------------------------	---------------------------



Renew cable harness and check airbag and belt tensioner system.

End of test

Renew reserve power source (C1) and repeat test step 6.

Reference value correct	Reference value incorrect
-------------------------	---------------------------

- Renew control unit (N2/2).
- Check function of warning lamp (A1e15).

End of test

Test step 7
 Test capacitance of reserve power source.
Not required for airbag 1/3

The reading should be taken when the indicator lamp for the reserve power source on the tester goes out (independent of control unit).

Control unit part no. 126 820 14 10
 Res. power source part no. 000 821 00 62
 C ≥ 4.0 mF

Control unit part no. 124 820 51 10
 and control unit part no. 002 820 97 10
 Res. power source part no. 000 821 02 62
 C ≥ 7.0 mF

Reference value correct	Reference value incorrect
-------------------------	---------------------------

Renew reserve power source (C1).

Renew control unit (N2/2).

Check function of warning lamp (A1e15).

End of test






Test instructions for tester 126 589 10 21 00

(revised)

Before testing with the tester, the airbag restraint system must be tested by means of the RS/SRS warning lamp (A1e15). With the ignition switched on, the RS/SRS warning lamp should light up for approx. 10 s, or approx. 4 s in vehicles with airbag 1/3. If necessary, check warning lamp or cable.



Each time before disconnecting the red test coupling/plug connection for airbag, 10-pin (X29/9), to connect the tester, the ignition key must be turned to position "0", the negative terminal of the battery disconnected and covered. Then reconnect the battery for the test.

Test step	Scope of test	Operation	Reference value	Possible causes if reference value not attained
1	Power supply	Ignition: OFF Disconnect 10-pin coupling (X29/9) and connect cable harness plug connector with tester. Ignition: ON	LED:  ON Battery voltage	Battery charge not OK Cable harness faulty
2 ¹⁾	Voltage transformer N24 (not installed in all vehicles)	Ignition: ON	LED:  ON U = 12 ± 1 V after 30 s	Voltage transformer faulty Reserve power source faulty Cable harness faulty
3	Resistance of airbag unit (R12/3) Collector ring	Ignition: ON Turn steering wheel to full lock (left and right)	LED:  ON R = 2 – 6 Ω	Contact between collector ring and carbon contact faulty Cable faulty Driver airbag unit faulty
	Insulation resistance	Ignition: ON Press  button	LED:  ON R ≥ 20 kΩ–EEE (EEE = ∞)	Cable harness faulty Airbag unit faulty

¹⁾ Not required for airbag 1/3

4	Resistance of belt tensioner, passenger's belt tensioner detonator (R12/2)	Ignition: ON	LED: ☒ ON R = 2 – 6 Ω	Cable faulty Belt tensioner unit faulty
	Detonators for driver's and passenger's belt tensioners (R12/1 and R12/2)		(Parallel circuit) R = 1 – 1.7 Ω	Cable faulty Belt tensioner unit faulty
	Insulation resistance	Ignition: ON Press \perp button	LED: ☒ ON R ≥ 20 kΩ–EEE (EEE = ∞)	Cable harness faulty Airbag unit faulty
5	Not required			
6 ¹⁾	Check charge of reserve power source (C1)	Ignition: ON	LED: ☒ ON ON Ref. value > 9	Cable faulty Reserve power source faulty
7 ¹⁾	Check capacitance of reserve power source (C1)	Ignition: ON	LED ☒ ON ON goes out, then take reading C ≥ 4.0 mF C ≥ 7.0 mF	Reserve power source faulty
	Observe assignment	Control unit part number	Capacitance of reserve power source	Reserve power source part number
		126 820 14 10 002 820 97 10 124 820 51 10	4.0 mF 7.0 mF 7.0 mF 7.0 mF	000 821 00 62 000 821 02 62 000 821 02 62 000 821 02 62

Further applications using the tester as a voltmeter or ohmmeter (in the context of the airbag test only)

8 Volt- meter (volts)	Voltage measurements	External power supply cable to 12 V battery	LED: ☒ ON U = 0 – 99.9 V	
9 Ohm- meter Ω	Resistance measurements		LED: ☒ ON R = 0 – 99.9 Ω	
10 Ohm- meter (kΩ)	Not possible with tester 126 589 10 21 00, if necessary, use only approved digital multimeter (e.g.: Sun, DMM 5), Avometer			

¹⁾ Not required for airbag 1/3