



1774-13800

- |                              |   |
|------------------------------|---|
| Screw (1) .....              | unscrew 6 each, screw in  |
| Chrome-plated rail (2) ..... | remove and install  |
| Holddown (5) .....           | unclip and clip in 2 each from mount (9) and pull out of wind deflector (6) toward the rear |
| Wind deflector (6) .....     | pull out of center mount (7)  |
| Wind deflector (6) .....     | carefully push out of duct including mount (8) left and right by means of a screwdriver     |
| Wind deflector (6) .....     | remove in upward direction  |

250/1

## Adjusting

---

If the wind deflector brushes against sun roof top panel when entering recess, the height can be adjusted by means of adjusting screw (arrow). If the wind deflector rattles in the center mount, the mount can be slightly pre-stressed. For this purpose, hold wind deflector in place at outer mounts, pull out of center mount in center range and bend slightly in upward direction. Gap dimension when closing between top panel and wind deflector 5 mm.

