124.82-37.00	Radio MB with CD Changer	As of MY 1994	Page 1 of 1

A2	Radio	4A	
A2/6	CD changer (in trunk)	2M	
F1	Fuse and relay box	0	
F1-1	Fuse 1, circuit 15R	6L	
F1-9	Fuse 9, circuit 30	6L	
W18	Ground (left front seat crossmember)		
	Ground location without designation, component grounded directly on engine, chassis or body.		
X1/8	Taillamp harness, radio/sound system connector	6E	
Z20	Shielding placed inside insulated tubing	3C	
Z20/2	Shielding placed inside insulated tubing	1D	
	Cross Section of Wire may differ from Values shown in Wiring Diagram. Changes in Cross Section of Wire will be shown framed.		
	Explanations and Notes of Wiring Diagram see Section 00-A Locations/Connections/Overview see Section 00-B/00-C		

