


All gasoline engines

Special tools



- Blow out spark plug wells in cylinder head before removing spark plugs.
- Remove spark plugs and check for deposits on electrodes. If deposits are present, replace spark plugs.
- If no deposits are present, regap spark plugs to 0.8 mm.
- Install spark plugs and torque to 25-30 Nm.

