



All Models

Check the following for damage and corrosion:


- Rear suspension control arms (semi-trailing arm suspension).



- Rear suspension links (multi-link suspension).




- A-arms and bushings.



0090

Suspension and body structure inspection

- Rocker panel.



- Bumper and mounting on body.

