



Model 124
with battery in engine compartment

Batteries without overflow protection feature

- Unscrew or pull out all caps according to design.



- Check fluid level in filler opening of cells and, if necessary, add fluid up to the inner marking.



Fluid	distilled water only
Quantity	as required