


All models

- Pull belt out completely and check for cut fibers and other damage such as burnt spots caused by cigarettes.
- Check that automatic reel functions correctly.
- Check locking function by pulling belt out quickly.
- Check belt strap for twisting.



Note:

If customer complains that belt does not roll up neatly, check whether belt is guided back manually as specified or whether it is twisted 180° behind panel caused by improper handling. Remove panel for this purpose.

- If customer refuses replacement of damaged belt, this should be noted on repair order.