



P40-5066-57

Prerequisites for checking

Vehicle in "ready-to-drive" condition:

- Operational vehicle filled with oil and coolant.
- Fuel tank full, compensate for missing fuel with appropriate additional weight in trunk.
- Spare tire and tools in vehicle.
- Vehicle unladen. Removal of luggage, fuel can or similar from vehicle.

Tire pressure	Check, correct if necessary.
Tires/disk wheels	Check wear pattern, tread depth and damage.
Visual inspection of vehicle underbody	For damage, corrosion of chassis and supporting parts of the body. Leaks at units and lines.
Wheel bearing play	Check (without dial gauge).
Play in steering components	Check (46-0110).
Pedal winch	Install part no. 000 589 18 31 00 on brake pedal.
Data sheet for chassis alignment	Use/fill out order no. B20.800.98.230.00.B-00/0291.

Special tools

