


Removal, installation

- 1 Unclip cover strip and remove.



- 2 Remove screws and take off cover in inward direction.

- 3 For installation proceed vice versa.

